

## UNITED STATES ENVIRONMENTAL PROTECTION AGENCY REGION IX 75 Hawthorne Street San Francisco, CA 94105-3901

December 6, 2022

Mr. Joshua Nandi Northrop Grumman Systems Corporation One Space Park Mail Stop: NGC CER-XE6D21 Redondo Beach, CA 90278 SENT VIA EMAIL

Re: Northrop Grumman Vapor Intrusion Work Plan Addendum #3. Former TRW Microwave Site, 825 Stewart Dr., Sunnyvale, California, TRW Microwave Superfund Site (CERCLIS ID# CAD009159088)

Dear Mr. Nandi:

Thank you for submitting the Northrop Grumman Systems Corporation (Northrop Grumman) Vapor Intrusion Work Plan Addendum #3. EPA requests the Addendum be revised to improve its readability and to address the following technical comments below:

- 1. Edit the Addendum's main text to include a summary description of the standard operation procedures (SOP) for the activities to be performed (e.g., soil gas installation and sampling, indoor/outdoor air sampling, differential pressure monitoring) and include the SOPs as attachments (or clearly reference the SOP location in the document).
- 2. Include an SOP for differential pressure monitoring and describe the associated QA/QC criteria. The monitoring should be performed over a period of one week and measurements recorded every five minutes.
- 3. Add laboratory reporting limits to Table 1.
- 4. Include a footnote in Table 1 to indicate that EPA will be notified immediately if indoor air results for TCE are above the accelerated response value of  $7 \mu g/m^3$  for commercial/industrial exposure and appropriate actions will be taken to confirm the results and implement mitigation measures.
- 5. Include a table (Table 2) for soil gas screening levels and laboratory reporting limits. Define the soil gas screening levels by using the indoor air levels for long-term exposure in Table 1 divided by the attenuation factor of 0.03.
- 6. Include a summary of the QA/QC metrics (e.g., QA/QC criteria for duplicated samples).

- 7. Include additional long-term (seven days) indoor air sampling using passive samplers in four locations (IA-2, IA-3, IA-4, IA-7). Include one long-term outdoor air sampling. Include a summary and SOP for the long-term passive sampling.
- 8. Include one additional sub-slab sampling location (SS-12) for spatial coverage as indicated in the figure attached.
- 9. Move sampling location IA-2 to the cubicles next to SS-7 (pending building walk through).
- 10. Provide the sequence of activities. EPA recommends the following sequence:
  - 1. Day Zero: Building walk through, check sub-slab ports and install SS-12
  - 2. Day 1: Start sampling
    - a. Begin differential pressure monitoring at tree sub-slab ports SS-2, SS-7 and SS-10
    - b. Start long-term passive indoor air sampling at four locations IA-2, IA-3, IA-4, and IA-7; and one outdoor location at HVAC intake.
  - 3. Day 2: One week after start of sampling on Day 1
    - a. Start the 10-hour indoor air sampling with SUMMA<sup>TM</sup> canisters in all indoor air locations (IA-1 to IA-9), and one outdoor location at HVAC intake
    - b. Stop and remove the differential pressure monitoring from sub-slab ports
    - c. Perform the sub-slab sampling in all sub-slab locations
- 11. Include a statement that after data collection and evaluation is completed, reviewed, and approved by EPA, the sub-slab ports will be decommissioned, upon consultation and approval by EPA.
- 12. Include a statement that a report will be submitted to EPA within 30 days of receipt of the results from the laboratory.

EPA requests that Northrop Grumman provide a Revised Work Plan Addendum within 30-days from the receipt of this letter. Please feel free to contact me anytime at <a href="mailto:abreu.lilian@epa.gov">abreu.lilian@epa.gov</a> or 415-972-3010 if you have any questions or comments.

Sincerely, LILIAN ABREU Digitally signed by LILIAN ABREU Date: 2022.12.06 14:01:30

Lilian Abreu, PhD Remedial Project Manager Superfund and Emergency Management Division

cc: Holly Holbrook, AECOM Cynthia Woo, Aptim Federal Services, LLC

